MAD DONNA

on

VISYS-Board

(Video-System-Board)

Very important!
(Sehr WICHTIG)

4-Way Joystick !!!

O JAMMA STANDARD

O MONITOR HORIZONTAL

O POWER CONSUMPTION

+5V.....5A

+12V..... 1A



RED



Poppenbütteler Bogen 44 22399 Hamburg / GERMANY

Phone: ++49/40/606020

Fax.: ++49 / 40 / 60 60 215

MAD DONNA by TUNING

28-pin Connector (JAMMA)

GND GND

	SOLDER SIDE	No.	No.	PARTS SIDE
	GND	A	1	GND
	GND	В	2	GND
	+5V	C	3	+5V
	+5V	D	4	+5V
L A		E	5	
	+12V	F	6	+12V
		H	7	
		I	8	
J		K	9	
A	SPEAKER (-)	L	10	SPEAKER (-
M DIP 1]	M	11	
14	GREEN	N	12	RED
A DIP 2	SYNC	P	13	BLUE
A	SERVICE	R	14	VIDEO GNI
TAST MERSON	AT BENDEYADY A	S	15	
	COIN 2	T	16	COIN 1
MATTHE	2P START	U	17	1P START
	2P UP	V	18	1P UP
	2P DOWN	W	19	1P DOWN
	2P LEFT	X	20	1P LEFT
	2P RIGHT	Y	21	1P RIGHT
	2P PUSH 1	Z	22	1P PUSH 1
	2P PUSH 2	a	23	1P PUSH 2
		b	24	
		С	25	
3.		d	26	
	GND	e	27	GND
				CND

GND

27 28

MAD DONNA - DIP SWITCH #1

	DIP-#1 COIN / CREDITS	Coins/Credits 1/1 2/2 3 2/1 3/1	ON	2 OFF OFF ON ON	No. Co. Co. Co. Co.	4	5	-6	7	8
X!	GIRLS "ON" NO GIRLS				ON OFF		*			
	DEMO SOUND O)N)FF			
	SCREEN TEST								-	ON OFF
	<u>DIP-# 2</u>		1	2	3	4	5	6	7	8
X!	DIFFICULTY	EASY NORMAL 'HARD VERY HARD	ON OFF							
X!	TIME PER ROUND	100 Seconds 90 Seconds 80 Seconds			OFF ON OFF					
X!	LIVES LIVES	3 5					ON OFF	7		



MAD DONNA DIP SWITCH MANUAL

DIP-SW1.

ITEN	ſ	1	2	3	4	5	6	7	8
	1 COIN	OFF	OFF						
	1 CREDIT								
COIN	2 COIN	ON	OFF						
	2 CREDIT								
	2 COIN	OFF	ON						
	1 CREDIT								
	3 COIN	ON	ON						
	1 CREDIT								
GIRL VIEW	YES			ON					
	NO			OFF					
DEMO	YES					ON			
SOUND	NO					OFF			
FREE PLAY	YES							ON	
	NO							OFF	
SCREEN	YES								ON
TEST	NO								OFF

DIP-SW2.

ITI	EM	1	2	3	4	วี	6	7	8
DIFFICULT	EASY	OFF	OFF						
	NORMAL	ON	OFF						
	HARD	OFF	ON						
	VERY HARD	ON	ON						
PLAYER	1COIN					ON			1
	3 PLAYER							<u> </u>	
	1COIN			1		OFF			
	5 PLAYER							1	
ROUND TIME	100 (SEC)			OFF	OFF			1	1
	90 (SEC)			ON	OFF			1	i
	80 (SEC)		1	OFF	ON			:	

